FIRE ALARM SYSTEM





## DESCRIPTION

## **DUCUMENTATION**

- INSTALLATION NOTE
  - 1. Remove a gong
  - 2. Wire the bell in the circuit.
- 3. Mount bell mechanism on 6" square standard outlet box with the striker facing down
- 4. The bell must be mounted a minimum of 8ft., above the floor, or, as close to the ceiling as possible.
- 5. Polarized bell provides Red(+) and Black(-) lead wires. When you install the bell, must be observe the polarity.

Series bells are low current, high decibel notification applianes for use in fire and burhlary systems or other signaling applications. The SSM (24VDC) Series is motor driven while the SSV (120VAC) Series utilizes a vibration mechanism.

The DC models are polarize for use with supervision circuitry.

## SPECIFICATION

Туре	HC-624B
Size Avaliable	6"
Voltages Avaliable	24VDC polarized, suppressed 20mA
Service Use	Fire alarm, geneal singaling, burglar alarm
<b>Operating Temperatuer Range:</b>	indoor or outdoor use 31 to 140 F
Termination:	Provided with 2 sets of leads for in/out wiring
Alarm bell sound level	95 db/10ft



